

Release Notes for Firmware of H&H TRL Series Electronic Loads

Contact H&H to check possibility of firmware update for your specific device. Provide serial number.

Concerning Components:

AI: Analog Interface Board
DI: Data Interface Board
UI: User Interface Board
GI: GPIB Interface Board

Höcherl & Hackl GmbH
Industriestr. 13
94357 Konzell
GERMANY
Tel.: 0049 09963/94301-0
Fax: 0049 09963/94301-84
support@hoecherl-hackl.com
www.hoecherl-hackl.com

Firmware Release: AI1.1.0 DI1.1.0 UI1.1.0

New Features/Added

- Added master-slave functionality.

Enhancements/Changed

- Improved synchronization of active interface in slave mode.
- Added additional user messages if the static operating mode differs from function-specific operating mode.

Bugfixes/Corrected

- Corrected bug of function execution when loading recall settings.

Backwards Compatible

Hardware: Yes

Software: Yes

Firmware Release: AI1.0.1 DI1.0.1 UI1.0.0

New Features/Added

- n.a.

Enhancements/Changed

- Changed default values for fan temperature thresholds.
- Extended functionality for visibility of SCPI commands/queries.

Bugfixes/Corrected

- Corrected frequency of modulation with rectangular waveform.

Backwards Compatible

Hardware: Yes

Software: Yes

Firmware Release: AI1.0.0 DI1.0.0 UI1.0.0

Initial Release